

CARY FILTERED RECEIVERS

CARY Filtered Receivers are designed to collect vacuumed waste in a container that utilizes a filter mounted inside the lid. The Filtered Receiver is used in conjunction with the FUJI Ring Compressor in vacuum applications of medium to lightweight dry waste. Available in either a 15- or 30-gallon capacity and can also be ordered on a stand so ring compressor is mounted below drum to minimize footprint. The filter has a perforated outer cylinder and an inner liner wrapped with a fine mesh (.009) screen. The filter itself is rated for 200-micron filtration.



FEATURES:

- Most economical, simple, and efficient method for vacuum application waste collection.
- Durable steel drum & lid.
- Each Receiver comes with properly sized Filter w/cover installed.
- Filter Cover is easily re-ordered & replaced and may even be cleaned & re-used.
- Filter Cover keeps filter cleaner for long lasting performance and minimum maintenance.

TECHNICAL SPECIFICATIONS:

- Inlet Filter operates at less than 1% pressure loss when properly sized for ring compressor.
- Polyester Filter Cover is flame-retardant with a bonded tacky side for maximum dirt holding capacity. Can be used at temperature of 300°F. Rated at 83% efficient @ 25 microns with minimal pressure loss.
- RECOMMENDED for use with ring compressors up to 5 HP.
- 1-1/2" and 2" hose connections are standard. Special configurations can be quoted.

Model	Description:	Dim. X (in.) approx.	Dim. Y (in.) approx.
R15P1.5	15 Gallon with 1-1/2" inlet & outlet	15	26
R15P2.0	15 Gallon with 2" inlet & outlet	15	26
R15PS1.5	15 Gallon with 1-1/2" inlet & outlet on Stand **	15	40
R15PS2.0	15 Gallon with 2" inlet & outlet on Stand **	15	40
R30P1.5	30 Gallon with 1-1/2" inlet & outlet	19	30
R30P2.0	30 Gallon with 2" inlet & outlet	19	30
R30PS1.5	30 Gallon with 1-1/2" inlet & outlet on Stand **	19	47
R30PS2.0	30 Gallon with 2" inlet & outlet on Stand **	19	47

****For correct fit-please specify Ring Compressor Model being used when ordering with Stand**

Visit our website: WWW.CARYMFG.COM